

# Section 18: Fuses, Heaters, Parameters

## FUSE LIST FOR FADAL VMC

LBL-0017 Rev. D 3-17-03

TYPE	AMPS	PART#	DESCRIPTION	RELAY	PART#	LOC	BRN	WHT	
<b>1100-1</b>									
F9	MDL	5	SPINDLE COOLER PUMP	K15	ELE-0070	TB2	18	17	
CB4	ETA	2.5	ELE-0098						
F10	AGC	2	DUAL PROBE INTERFACE - M64 / M65	K16	ELE-0070	TB2	36	RET	
F11	AGC	2	A-AXIS BRAKE SOLENOID (OPT.) - M60 / M61	K17	ELE-0937	TB2	40	RET	
F14	AGC	2	EMERGENCY STOP	controls K1 & K2		K20	ELE-0937	TB2	26
F16	MDA	10	120 VAC Power Input to 1100-1						
F17	AGC	2	SERVO CHASSIS POWER			TB1	8	9	
F18	AGC	2	COOLANT TWO PUMP	K22	ELE-0070	TB2	24	23	
F21			M18 - Air Indexer	K25		TB2	14	15	
F22	MDL	5	FLOOD COOLANT PUMP	K26	ELE-0070	TB2	28	27	
CB7	ETA	2.5	ELE-0098	for 60Hz, all machines except 2016L and 3016L					
CB7	ETA	3.5	ELE-0993	for 2016L, 3016L, or 50Hz					
F23	AGC	1	AXIS AMP FANS			TB2	2	1	
F25	MDL	5	120 VAC PENDANT			TB2	4	3	
F27	AGC	3	CABINET COOLING FANS			TB2	10	9	
F29	AGC	2	MP12 TRANSFORMER			TB2	6	5	
CB1	KD1	2.5	ELE-0086						
F30	AGC	2	VALVE COIL, HI RANGE IDLER ARM	K27	ELE-0937	TB2	14	13	
F31			M68 / 69	K28	ELE-0070	TB2	16	RET	
F34	AGC	2	VALVE COIL, LO RANGE IDLER ARM	K10	ELE-0937	TB2	34	33	
F40			M66 / 67	K31	ELE-0070	TB2	20	RET	
F41			SPARE-2	K32		TB2	22	21	
F42	MDL	3	CE DOOR LOCK (Power for 2030 board)			TB2	8	7	
F43			SPARE			TB2	12	11	
CB2	KD1								
F44	AGC	2	B-AXIS BRAKE SOLENOID (OPT.) - M62 / 63	K8	ELE-0937	TB2	38	RET	
<b>1100-2</b>									
F1	AGC	1	SPINDLE ON	controls K3		K7	ELE-0937*	TB1	19
F3	AGC	1	SPINDLE REVERSE	controls K4		K9	ELE-0937*	TB1	17
F4	AGC	2	SERVO TURRET			K12	ELE-0937*	TB1	31
CB7	KD1	2.5	ELE-0086						
F5	AGC	1	TURRET MOTOR REVERSE	controls K5		K11	ELE-0937*	TB1	7 & 5
F6	ABC	5	TURRET MOTOR (GENEVA) passes thru K33			K12	ELE-0070	TB1	6
or	ABC	5	TURRET MOTOR (SERVO) passes thru K33			K12	ELE-0937*	TB1	6
CB2	KD1	2.5	ELE-0086	for 60Hz					
CB2	KD1	3	ELE-0087	for 50Hz					
F7	AGC	1	ATC SLIDE MOTOR REVERSE	controls K6		K13	ELE-0937*	TB1	3 & 5
F8	AGC	5	ATC SLIDE MOTOR			K14	ELE-0070	TB1	2
CB1	KD1	2.5	ELE-0086	for 60Hz					
CB1	KD1	3	ELE-0087	for 50Hz					
F13	AGC	2	WAY LUBRICATOR			K19	ELE-0937	TB1	11
F15	AGC	2	AIR THROUGH SPINDLE			K21	ELE-0937	TB1	15
F19	AGC	2	VALVE COIL, SPINDLE ORIENTATION			K23	ELE-0937	TB1	27
F20	AGC	2	VALVE COIL, DRAWBAR			K24	ELE-0937	TB1	23
F24	MDL	3	SPINDLE MOTOR FAN					TB1	29
CB8	KD1	3	ELE-0087	for 60Hz					
CB8	KD1	5	ELE-0089	for 50Hz					
F26	MDA	10	120 VAC Power Input to 1100-2						
F28	AGC	3	COOLING FAN			TB1	21	22	
F32			Spare-4			K29		TB1	9
F33			Spare-1			K30		TB1	13
<b>1100-3 PALLET CHANGER</b>									
F1	AGC	1	HYDRAULIC PUMP STARTER			K1	ELE-0070	J2	1
F2	AGC	1	PALLET TO TABLE VALVE			K2	ELE-0937	J2	3
F3	AGC	1	PALLET TO STORAGE VALVE			K3	ELE-0937	J2	5
F4	AGC	1	OPEN PALLET DOOR SOLENOID			K4	ELE-0937	J2	7
F5	AGC	1	UNCLAMP SOLENOID			K5	ELE-0937	J2	9
F9	MDA	10	MAIN 120 VAC POWER SUPPLY						
F10	AGC	3	24V DC TO LIGHT CURTAIN						
<b>MISCELLANEOUS</b>									
F1	MDL	7	120 VAC INPUT			K1	ELE-0071		DC POWER SUPPLY
AGC	3		DISK DRIVE POWER				1270		
			AUGER PUMP			K1	ELE-0070		1310
			AUGER VALVES, CONTACTOR, ETC			K2-4, K6, K101	ELE-0937		1310
CB1	ETA	3.5	ELE-0993	DUAL-ARM TOOL CHANGER 120 VAC		K1-K4	ELE-0937		1330
CB1	KD1	10	ELE-1492	SERVO TURRET POWER SUPPLY (1350-0 uses MDA 6 fuse)					1350-1
F1	MDA	15		CHILLER AND PUMP					1560
F1	MDL	5		HYDROSWEEP CONTROL		K1-9	ELE-0070		1790
F1, F2	AGC	10		SERVO TURRET AMP					1810-0-1
F1	AGC	2		AIR/OIL CONTROL					1980
				BEACON, 32MP POWER SUPPLY		K1, K2	ELE-0070		.1990-1 & 1990-2
				SPINDLE RELAY CONTROL		K1	ELE-0937*		2000 (CE machines)
				AXIS CONTACTOR CONTROL		K8	ELE-09372030		(CE machines)
	BLN OR KLK	30	ELE-0837	SERVO AMP CHASSIS INPUT (AC BRUSHLESS)					
	KTK OR KLK	20	ELE-0994	SERVO AMP CHASSIS OUTPUT (AC BRUSHLESS)					
	T16L250AC			SERVO COOLANT AMP					in 120V Inlet or Amp

Solid state relays are: ELE-0070 (Crouzet GA8-6802 or Magnecraft 7052-04-B-03-V, rated 3 amps, color black), ELE-0937 (Crouzet M-0ACS-315, rated 1 amp, color yellow, or Grayhill 70Y14350, color green) (Grayhill 70Y14303 may be substituted for those marked \*\*\*), ELE-0071 (Grayhill, 70Y21084, drops out at 4.7V, color white)

All mechanical relays are ELE-0072 (Omron MY4N-AC110/120 or equivalent).

**THERMAL OVERLOAD HEATERS:** B4.15 Coolant Thru Spindle Pump (3/4 Hp)      B4.85 Pallet Changer Hydraulic Pump (1 Hp)      B12.8 Wash Down Pump (3 Hp)

VMC with fuses at Main Disconnect ***		INPUT VOLTAGE		AMPERAGE	CLASS
60Hz 3-Phase	2216 / 3016 / 4020	208V / 240V / 480V	60Hz 3-phase	45 / 40 / 20	RK1, 600V
	4020A / 5020A / 6030 / 8030 & HT	208V / 240V / 480V	60Hz 3-phase	50 / 45 / 25	RK1, 600V
	All VHT models	230V	60Hz 3-phase	60	RK5, 600V
Single Phase	All models except VHT	240V	60Hz 1-phase	40 (45 for HT models)	RK5, 600V
50Hz 3-Phase	2216 / 3016 / 4020	380-415V	50Hz 3-phase	25	RK5, 600V
	6030 / 8030 & all HT models	380-415V	50Hz 3-phase	30	RK5, 600V
	All VHT models	230V	50Hz 3-phase	60	RK5, 600V

\*\*\* Machines with slant sheet metal have a circuit breaker in place of fuses at the main power disconnect

## FUSE LIST FOR EMC

Fadal EMC Fuse List LBL-0501 Rev. A 2-4-03

.....TYPE . AMPS .. PART#.....	DESCRIPTION.....	RELAY .....	PART#.....	LOC .....	BRN.....	WHT.....
<b>1100-1</b>						
F9 .....MDL.....5 .....	SPINDLE COOLER PUMP .....	K15 .....	ELE-0070.....	TB2 .....	18 .....	17
CB4 .....ETA.....2.5 .....	ELE-0098 .....					
F10 .....AGC.....2 .....	DUAL PROBE INTERFACE M64 / M65.....	K16 .....	ELE-0070 .....	TB2 .....	36 .....	RET
F11 .....AGC.....2 .....	A-AXIS BRAKE SOLENOID M60 / M61 .....	K17 .....	ELE-0937 .....	TB2 .....	40 .....	RET
F14 .....AGC.....2 .....	EMERGENCY STOP controls K1 & K2 .....	K20 .....	ELE-0937 .....	TB2 .....	26 .....	-
F16 .....MDA.....10 .....	120 VAC INPUT TO 1100-1 .....					
F17 .....AGC.....2 .....	AXIS AMPLIFIER CHASSIS POWER .....			TB1 .....	8 .....	9
F18 .....AGC.....2 .....	COOLANT TWO PUMP .....	K22 .....	ELE-0070 .....	TB2 .....	24 .....	23
F21 .....MDL.....5 .....	M18 .....	K25 .....	ELE-0070 .....	TB2 .....	14 .....	15
F22 .....MDL.....5 .....	FLOOD COOLANT PUMP .....	K26 .....	ELE-0070 .....	TB2 .....	28 .....	27
CB7 .....ETA.....2.5 .....	for 60HZ, all machines except 2016L and 3016L .....					
CB7 .....ETA.....3.5 .....	for 2016L, 3016L, or 50Hz .....					
F23 .....AGC.....1 .....	AXIS AMP FANS .....			TB2 .....	2 .....	1
F25 .....MDL.....5 .....	120 VAC PENDANT .....			TB2 .....	4 .....	3
F27 .....AGC.....3 .....	CABINET COOLING FANS .....			TB2 .....	10 .....	9
F29 .....AGC.....2 .....	MP12 TRANSFORMER .....			TB2 .....	6 .....	5
CB1 .....KD1.....2.5 .....	ELE-0086 .....					
F30 .....AGC.....2 .....	VALVE COIL, HI RANGE IDLER ARM .....	K27 .....	ELE-0937 .....	TB2 .....	14 .....	13
F31 .....AGC.....2 .....	M68 / 69 .....	K28 .....	ELE-0070 .....	TB2 .....	16 .....	RET
F34 .....AGC.....2 .....	VALVE COIL, LO RANGE IDLER ARM .....	K10 .....	ELE-0937 .....	TB2 .....	34 .....	33
F40 .....AGC.....2 .....	M66 / 67 .....	K31 .....	ELE-0070 .....	TB2 .....	20 .....	RET
F41 .....AGC.....2 .....	SPARE-2 .....	K32 .....	ELE-0070 .....	TB2 .....	22 .....	21
F42 .....MDL.....3 .....	CE DOOR LOCK (2030-0A).....			TB2 .....	8 .....	7
F43 .....AGC.....2 .....	SPARE .....			TB2 .....	12 .....	11
CB2 .....KD1.....- .....						
F44 .....AGC.....2 .....	B-AXIS BRAKE SOLENOID M62 /63.....	K8 .....	ELE-0937 .....	TB2 .....	38 .....	RET
<b>1100-2</b>						
F1 .....AGC.....1 .....	SPINDLE ON controls K3.....	K7 .....	ELE-0937 .....	TB1 .....	19 .....	20
F3 .....AGC.....1 .....	SPINDLE REVERSE controls K4 .....	K9 .....	ELE-0937 .....	TB1 .....	17 .....	18
F4 .....AGC.....2 .....	SERVO TURRET .....	K12 .....	ELE-0937 .....	TB1 .....	31 .....	-
CB7 .....KD1.....2.5 .....	ELE-0086 .....					
F5 .....AGC.....1 .....	TURRET MOTOR REVERSE controls K5 .....	K11 .....	ELE-0937 .....	TB1 .....	7 & 5 .....	-
F6 .....ABC.....5 .....	TURRET MOTOR (GENEVA) passes thru K33.....	K12 .....	ELE-0070 .....	TB1 .....	6 .....	8
-or-.....ABC.....5 .....	TURRET MOTOR (SERVO) passes thru K33 .....	K12 .....	ELE-0937 .....	TB1 .....	6 .....	8
CB2 .....KD1.....2.5 .....	for 60Hz .....					
CB2 .....KD1.....3 .....	for 50Hz .....					
F7 .....AGC.....1 .....	ATC SLIDE MOTOR REVERSE controls K6.....	K13 .....	ELE-0937 .....	TB1 .....	3 & 5 .....	-
F8 .....AGC.....5 .....	ATC SLIDE MOTOR.....	K14 .....	ELE-0070 .....	TB1 .....	2 .....	4
CB1 .....KD1.....2.5 .....	for 60Hz .....					
CB1 .....KD1.....3 .....	for 50Hz .....					
F13 .....AGC.....2 .....	WAY LUBRICATOR .....	K19 .....	ELE-0937 .....	TB1 .....	11 .....	12
F15 .....AGC.....2 .....	AIR THROUGH SPINDLE .....	K21 .....	ELE-0937 .....	TB1 .....	15 .....	16
F19 .....AGC.....2 .....	VALVE COIL, SPINDLE ORIENTATION .....	K23 .....	ELE-0937 .....	TB1 .....	27 .....	28
F20 .....AGC.....2 .....	VALVE COIL, DRAWBAR .....	K24 .....	ELE-0937 .....	TB1 .....	23 .....	24
F24 .....MDL.....3 .....	SPINDLE MOTOR FAN.....			TB1 .....	29 .....	30
CB8 .....KD1.....3 .....	for 60Hz .....					
CB8 .....KD1.....5 .....	for 50Hz .....					
F26 .....MDA.....10 .....	120 VAC INPUT TO 1100-2.....					
F28 .....AGC.....3 .....	COOLING FAN .....			TB1 .....	21 .....	22
F32 .....AGC.....2 .....	SPARE-4 .....	K29 .....		TB1 .....	9 .....	10
F33 .....AGC.....2 .....	SPARE-1 .....	K30 .....		TB1 .....	13 .....	14
<b>MISCELLANEOUS</b>						
.....KTK or KLK20 .....	ELE-0994 .....					
.....AGC.....3 .....	DISK DRIVE POWER.....				1270-2 .....	
F1 .....TR5 373 .....	ELE-1485 .....				1290-0 .....	
.....MDL.....7 .....	BEACON, 32MP POWER SUPPLY .....	K1,K2 .....	ELE-00701990-1 & 1990-2 .....			
.....AGC.....2 .....	POWER SUPPLY MAIN 120 VAC.....	K1 .....	ELE-0071DC Power Supply .....			
.....AGC.....2 .....	SPINDLE RELAY CONTROL .....	K1 .....	ELE-0937 .....		2000 (CE machines) .....	
.....AGC.....2 .....	AXIS CONTACTOR CONTROL .....	K8 .....	ELE-0937 .....		2030 (CE machines) .....	

Solid state relays are : ELE-0070 (Crouzet GA8-6B02 or Magnecraft 70S2-04-B-03-V, rated 3 amps, color black),  
 ELE-0937 (Crouzet M-0AC5-315, rated 1 amp, color yellow)  
 ELE-0071 (Grayhill, 70YY21084, drops out at 4.7V, color white)  
 All mechanical relays are ELE-0072 (Omron MY4N-AC110/120 or equivalent).

**TOOL ROOM MILL FUSE LIST**

Fuse List for Tool Room Mill - LBL-0500 Rev. A 1-29-03

<b>FUSETYPE</b>	<b>AMPS</b>	<b>PART#</b>	<b>DESCRIPTION</b>	<b>RELAY PART#</b>	<b>PINK</b>
<b>WHITE</b>					
<b>1100-5</b>					
<b>TERMINALS</b>					
CB1	KD1	5	ELE-0089	18 VAC INPUT TO 1100-5	
				SPINDLE FWD (controls K3 relay)	K7 ELE-1649 TB2 19 20
				SPINDLE REV (controls K4 relay)	K9 ELE-1649 TB2 17 18
F1	TR5 374	2	ELE-1487	SPARE (jumper selectable) optional	K40 ELE-1649 TB3 1 2
F2	TR5 374	2	ELE-1487	SPARE (jumper selectable) optional	K41 ELE-1649 TB3 3 4
F14	TR5 374	2	ELE-1487	EMERGENCY STOP (controls K1 & K2 relays)	K20 ELE-1649 TB2 26 --
F15	TR5 374	2	ELE-1487	AIR THROUGH SPINDLE	K21 ELE-1649 TB2 15 16
F18	TR5 374	2	ELE-1487	COOLANT TWO PUMP	K22 ELE-1649 TB2 24a 23a
F20	TR5 374	2	ELE-1487	DRAWBAR	K24 ELE-1649 TB2 23 24
F25	TR5 374	2	ELE-1487	BEACON	K6 ELE-1649 TB5 1 2
F11	TR5 374	2	ELE-1487	M60 / M61	K17 TB2 39 & 40
<b>DC POWER SUPPLY</b>					
CB	KD1	5		POWER SUPPLY MAIN 240 VAC	

Tool Room Mill uses 24 VDC solenoids.

All solid state relays except K17 are DC. Use ELE-1649 Crouzet type MODC5, Grayhill type 70M-ODC5, or equivalent. The relay used for K17 is dependent on what M60/M61 controls.

All mechanical relays have 24 VDC coil. Use ELE-1110, Omron MY4N-DC24.

All fuses are Wickman TR5 No. 374 or Littlefuse LT-5 665 series subminiature fuses.

Use an insulated alligator clip to remove fuse. Always power off machine before removing or inserting fuses.

**Table 1: Parameter Settings**

Options in SETP Mode	Available Formats	Factory Setting	Customer Preference
There are two Program Formats available. Do you want 6MB/10M/11M compatibility (Format 2)?	1&2	2	
Enter the default Baud rate (the rate after power on)	1&2	6	
Should spindle come on automatically after a tool change when the M6 had to turn the spindle off?	1&2	1	
Enter the Axis Configuration	1&2		
Enter X,Y,Z travel	1&2		
Enter the Pendant style	1&2	3	
Enter the default value (G0,G1)	1&2	2	
Enter the A axis ratio	1&2		
Does M60 turn on the A axis brake?	1&2		
Enter the default value (G90,G91)	1&2	1	
Enter the B axis ratio	1&2		
Does M62 turn on the B axis brake?	1&2		
Enter the default value (G17,G18,G19)	1&2	1	
Enter the Tool Changer capacity	1&2		
Should a Fixed Cycle execute immediately?	1		
Enter the Spindle RPM Adjustment factor The factor must be between 0 and 31	1&2		
Enter the Spindle Drive Type and RPM	1&2		
Enter the Spindle Orientation RPM Adjustment factor The factor must be between 0 and 31	1&2		
Enter the default value (Inch, Metric)	1&2	1	
Enter M7, M8 preference	1&2	2	
Is your 3 Phase power more than 5% low?	1&2	2	
Select Punch Output format	1&2	2	
Enter the N Word sequence configuration	2	1	
Will the Tool Compensation Table have the radius or the diameter?	2	1	
Enter the default outside corner movement (M96,M97)	1&2	1	
Select the number of binary buffers for CNC look ahead	1&2	5	
Do you have the High Torque or Rigid Tapping option?	1&2		
Do you want the spindle to turn off when exiting JOG or MANUAL DATA INPUT?	1&2	1	
Enter the Engagement factor for the Tool Turret Geneva Gear The factor must be between 1 and 50 <b>Note:</b> For Servo Turret the factor must ALWAYS be 1	1&2		

**Table 1: Parameter Settings**

Options in SETP Mode	Available Formats	Factory Setting	Customer Preference
Turn the Command Menus ON or OFF?	1&2	3	
Do you have a Pallet Changer?	1&2		
Enter the Gain factor for Rigid Tapping The factor must be between 0 and 255	1&2		
Enter the Ramp factor for Rigid Tapping The factor must be between 0 and 255	1&2		
Enter the Graphics Aspect Ratio of Y to X	1&2	65	
Select the Automatic Tool Timer mode	1&2	1	
Enter the Motor Overload factor The factor must be between 1 and 8	1&2	2	
Select the Screw Pitch type	1&2		
Select the Maximum Rapid Feed Rate	1&2		
Enter the X, Y, & Z Ramp Length factor The factor must be between 50 and 200	1&2		
Enter the Z Gain during Rigid Tapping	1&2		
Do you have a vector drive (10 RPM min).	1&2		
Display the axis following error or Load?	1&2	1	
Automatically apply the A or B brake during Idle Time?	1&2	2	
Which rotary axis is installed on this pallet	1&2	1	
Do you have the 5th axis programmable head attachment?	1&2	1	
Enter the detail desired for G0 moves between 2 to 250 (241=Off)	1&2	241	
Do you have air valve feedback?	1&2	2	
Wait until spindle is at-speed before next block is executed?	1&2	1	
Enter slide hold ramp factor between 1 to 10 (10 is Standard)?	1&2	10	
Is this a Manual Machine with 1 MPG for each Axis?	1&2		

---

**Machine Parameters**

This section covers parameter settings and their purpose.

To enter the parameter setting area of a Fadal VMC, type “**SETP**” at the “**ENTER NEXT COMMAND**” prompt and press the <**ENTER**> key.

To enter the parameters using the menus; enter the “**Function Menu**” then select “**2 Memory**” then “**6 Settings**” and “**2 Parameters**”.

The selected parameter will be stated under the parameters listed for that page with all the possible selections and the current selection with an “\*” sign.

To navigate the parameters, the <**ENTER**> key will move to the next parameter each time it is pressed, the “**D**” key will move to the next line down, the “**U**” key will move to the last line above and the “**P**” will move to the next page of parameters.

To change a parameter, select the parameter and enter the number of the setting to be changed to and press the <**ENTER**> key.

Many of the parameter changes will require machine to be powered off and back on to make the change take effect.

**Note:** Machine factory set parameter settings are located inside the pendant door.

**Note:** The current machine software will have three pages of parameters. Older software revisions may not have all of the parameters listed in this document.

---

**Machine Parameters:  
Page One**

**FORMAT** DO YOU WANT MAXIMUM 6MB/10M/11M CAPABILITY?

- 1)NO, ORIGINAL FADAL STYLE – FORMAT 1
- 2)YES, FORMAT 2

THERE ARE TWO PROGRAM OPERATION FORMATS AVAILABLE.

This parameter allows the user to select Fanuc 6MB/10M/11M compatibility. The operational difference between the two formats depends upon the coding used.

**BAUD RATE** ENTER DEFAULT BAUD RATE (THE RATE AFTER POWER-ON)

- 1) 110    5) 1200    9) 19200
- 2) 150    6) 2400    10) 38400
- 3) 300    7) 4800    11) 57600
- 4) 600    8) 9600    12) 115200

The operator may select the desired communications baud rate.

**SPINDLE AFTER M6** SHOULD SPINDLE COME ON  
AUTOMATICALLY AFTER A TOOL CHANGE  
WHEN THE M6 HAD TO TURN THE SPINDLE  
OFF?

- 1)NO (FADAL RECOMMENDS THIS RESPONSE)
- 2)YES

IF YES, ALL PERSONNEL MUST BE AWARE OF THE POSSIBILITY OF OVER SPEEDING A TOOL BEFORE THE NEW S-WORD IS ENCOUNTERED

When this parameter is selected as YES, the spindle automatically turns on after the tool change. The spindle comes on at the last programmed spindle speed. This may cause an overspeed of the next tool. **It is recommended that this parameter is set to number 1.**



**AXES: X,Y,Z** ENTER THE AXIS CONFIGURATION

- 1)A
- 2)A, B
- 3)X,Y,Z
- 4)X,Y,Z,A
- 5)X,Y,Z,A,B
- 6)X,Y,Z,B
- 7)C only

When selecting the axes, the machine must be powered off. When the power is returned the axes selected will be active. COLD START must be performed. The axes that are not selected will be inactive, the CPU will not look for them or try to move them.

**TRAVEL** ENTER X,Y,Z TRAVEL

- |                |                 |                 |                 |
|----------------|-----------------|-----------------|-----------------|
| 1) X22 Y16 Z20 | 8) X40 Y20 Z28  | 15) X50 Y20 Z20 | 22) X65 Y35 Z34 |
| 2) X20 Y12 Z20 | 9) X60 Y30 Z30  | 16) X50 Y20 Z28 | 23) X85 Y35 Z34 |
| 3) X45 Y25 Z24 | 10) X22 Y16 Z28 | 17) X80 Y30 Z30 | 24) X30 Y14 Z14 |
| 4) X45 Y25 Z32 | 11) X20 Y16 Z20 | 18) X30 Y20 Z24 |                 |
| 5) X22 Y13 Z20 | 12) X20 Y16 Z28 | 19) X30 Y20 Z32 |                 |
| 6) X20 Y13 Z20 | 13) X30 Y16 Z20 | 20) X20 Y20 Z24 |                 |
| 7) X40 Y20 Z20 | 14) X30 Y16 Z28 | 21) X20 Y20 Z32 |                 |

The machine travel limits are selected with this parameter. This parameter will default to selection 7 if parameters are lost.

**DANGER!**

Serious damage to machine may occur if this parameter is set incorrectly.

**PENDANT** ENTER THE PENDANT STYLE

- 1)KEYBOARD BESIDE THE VIDEO TUBE
- 2)KEYBOARD BELOW THE VIDEO TUBE
- 3)SAME AS 2 BUT MOUNTED ON FULL-ENCLOSURE CHIP GUARDS

Select the appropriate pendant location for the machine. When option 2 is selected the table may make a Y axis positive move before a tool change. This occurs only when the Y axis is five inches or more, in the negative direction, from the cold start position.

**DEFAULT: G0** ENTER THE DEFAULT VALUE

- 1)G0
- 2)G1

The code selected is active at power on and when entering the MDI mode. The G0 is rapid travel and the G1 is linear interpolation (travels at a stated feedrate).

**A-AXIS RATIO** ENTER A-AXIS RATIO

**Note:** Displayed only when  
A axis selected

- 1) 90:1
- 2) 180:1
- 3) 360:1
- 4) 120:1
- 5) 72:1
- 6) COOLANT
- 7) 60:1
- 8) 144:1

Select the appropriate gear ratio for the rotary table being used or select the servo coolant option (see rotary table nameplate for ratio).

**M60/A-AXIS BRAKE** DOES M60 TURN ON THE A-AXIS BRAKE?

**Note:** Displayed only when  
A axis selected

- 1) YES
- 2) NO

Select the option desired to activate or de-activate the air for the axis brake.

**DEFAULT: G90** ENTER THE DEFAULT VALUE

- 1)G90
- 2)G91

The code selected is active at power on and when entering the MDI mode. The G90 is absolute positioning and the G91 is incremental positioning.

**B-AXIS RATIO** ENTER B-AXIS RATIO  
**Note:** Displayed only when  
B axis selected

- 1) 90:1
- 2) 180:1
- 3) 360:1
- 4) 120:1
- 5) 72:1
- 6) COOLANT
- 7) 60:1
- 8) 144:1

Select the appropriate gear ratio for the rotary table being used or select the servo coolant option (see rotary table nameplate for ratio).

**M62/B-AXIS BRAKE** DOES M62 TURN ON THE B-AXIS BRAKE?  
Note: Displayed only when  
B axis selected

- 1)YES
- 2)NO

Select the option desired to activate or de-activate the air for the axis brake.

**DEFAULT: G17** ENTER THE DEFAULT VALUE

- 1)G17
- 2)G18
- 3)G19

This parameter is used to select the default machine plane. The G17 selects the XY plane, the G18 selects the ZX plane and the G19 selects the YZ plane.

**TOOL CHANGER** ENTER THE TOOL CHANGER CAPACITY  
CAP

- 1) 16 TOOL ATC
- 2) 21 TOOL ATC
- 3) 30 TOOL ATC
- 4) 24 TOOL DATC (Dual Arm Tool Changer)
- 5) 32 TOOL DATC (Dual Arm Tool Changer)
- 6) 62 TOOL DATC (Dual Arm Tool Changer)
- 7) NONE (TRM)

Select the appropriate tool changer capacity

**IMM. FIXED CYCLE** SHOULD A FIXED CYCLE EXECUTE IMMEDIATELY?

**Note:** Displayed only when  
Format 1 is selected.

- 1)YES
- 2)NO, ONLY IF X OR Y DIMENSION WORDS ARE IN THE DEFINITION LINE

A YES response causes a fixed cycle to be executed immediately upon definition at the current axis location. A NO response requires axis motion to activate the fixed cycle.

**RPM FACTOR** ENTER THE SPINDLE RPM ADJUSTMENT FACTOR. THE FACTOR MUST BE BETWEEN 0 AND 31.

This parameter adjusts the speed command signal voltage from the spindle controller card to the spindle drive in small increments in order to adjust the spindle RPM. Adjustment procedure: run the spindle at the desired RPM with a M49. Measure the spindle speed with a tach or read the RPM on the spindle vector drive (remember that the drive is motor speed so you must account for the pulley ratio). Change the RPM factor for the closest RPM.

**SPINDLE TYPE** ENTER THE SPINDLE DRIVE TYPE & RPM

- 1)10,000 HI/LOW
- 2)10,000 3 STEP
- 3)15,000 DIRECT
- 4)5,000 HI/LOW
- 5)6,500 HI/LOW
- 6)3750 WYE/DEL.
- 7)7500 WYE/DEL.
- 8)5000 DIRECT
- 9)15K WYE/DEL.

Select the correct spindle type for the machine. If set incorrectly the spindle RPM will most likely be incorrect and performance will be poor. The RPM is the maximum spindle RPM and the type after the RPM is: DIRECT which means one belt selection only, 3 STEP has three belt ranges but must be changed manually, HI/LOW is changed between two range is performed by idler arms or the WYE/DELTA changes motor wiring configuration by using relays.

**ORIENTATION FACTOR** ENTER THE SPINDLE RPM ADJUSTMENT FACTOR THE FACTOR MUST BE BETWEEN 0 AND 31

This parameter adjusts the speed command signal voltage from the spindle controller card to the spindle drive in small increments in order to adjust the spindle RPM during orientation. Find a factor that works for both high and low range.

To set, observe the orientation of the spindle. If it appears to be too fast with overshooting then lower factor, if it is too slow or does not always go around far enough then increase the factor. Check both ranges before completing selection. Normal setting is around 10 to 12.

---

**Machine Parameters:  
Page Two**

**DEFAULT: INCH** ENTER THE DEFAULT VALUE

- 1)INCH
- 2)METRIC

The operator selects the mode (inch or metric) for the machine. The G70, G71, G20 and G21 check this setting to verify the operational mode.

**M7-FLOOD M8-MIST** ENTER M7, M8 PREFERENCE

- 1)M7 IS FLOOD COOLANT, M8 IS MIST
- 2)M8 IS FLOOD COOLANT, M7 IS MIST

The operator may select either M7 or M8 as the flood coolant code. This selects the appropriate electrical outlet on the back of the machine.

**3 PHASE NO 5% LOW: NO** IS YOUR 3 PHASE POWER MORE THAN 5% LOW?

- 1)YES
- 2)NO

The selection chosen is based upon the building power supply. This lowers the rapid rate by 5% to reduce the fault point when the input power is too low. This may be selected if the input power has a large voltage variance or low input such as 208 VAC.

**PU FORMAT**      SELECT PUNCH OUTPUT FORMAT

- 1) PUNCHED TAPE FORMAT (TELETYPE STYLE)
- 2) COMPUTER FILE FORMAT (NO NULLS)

This parameter is set to file for computer use. The punch tape format is used when a tape reader is used.

**N-WORDS ORDERED**      ENTER THE N-WORD SEQUENCE CONFIGURATION

**Note:** Displayed only when  
Format 2 is selected.

- 1) THE N-WORDS ARE IN ASCENDING NUMERICAL ORDER OR THE PROGRAM WILL BE RENUMBERED AFTER INPUT.
- 2) THE N-WORDS ARE NOT IN ORDER.

The CNC 88 requires each block of NC code to have sequence numbers in numerical order. Since the 6MB/10M/11M controls do not require block numbers in numerical order, select option number 2. Upon tape input the CNC will add sequence numbers for reference. Otherwise, after tape input the program must be renumbered if the sequence numbers are not in numerical order.

**TOOL TABLE**      WILL THE TOOL COMPENSATION TABLE HAVE THE RADIUS OR DIAMETER?

**Note:** Displayed only when  
Format 2 is selected.

- 1) DIAMETER
- 2) RADIUS

The cutter offset specification in the tool compensation table may be defined as a diameter or radius.

**CRC MODE**      ENTER THE DEFAULT OUTSIDE CORNER MOVEMENT

- 1) M96 – ROLL
- 2) M97 – INTERSECTIONAL

This parameter selects the default mode for intersectional cutter radius compensation.

**BINARY BUFFERS:** SELECT THE NUMBER OF BINARY BUFFERS  
**255** LOOKAHEAD.

- 1) 15    3) 50    5) 255
- 2) 30    4) 100

The BINARY BUFFERS parameter can be changed to increase or decrease the control look ahead. The factory sets the buffers at 255. This is the most effective for programs with many small moves that must be executed rapidly. This parameter is used to more efficiently utilize the Run Time Menu. The smaller the buffers the more quickly the Run Time Menu changes will take effect in the program.

**HIGH TORQUE** DO YOU HAVE THE HIGH TORQUE OPTION  
OR RIGID TAP OPTION?

- 1)NO
- 2)YES

This parameter is for machines with the hydraulic Hi/Low system. A yes allows more time for the belt change process required by the hydraulic system.

**SPINDLE OFF** DO YOU WANT THE SPINDLE TO TURN OFF WHEN EXITING JOG OR MANUAL  
DATA INPUT?

- 1)NO
- 2)YES

The Fadal recommended setting is NO.

**TURRET FACTOR** ENTER THE ENGAGEMENT FACTOR FOR THE TOOL TURRET GENEVA GEAR  
THE FACTOR MUST BE BETWEEN 1 AND 50 (1 FOR SERVO TURRET)

This parameter adjusts the position of the Geneva gear with the Geneva wheel. For VMCs equipped with the servo turret, this factor MUST always be 1. This should be adjusted for the pin of the Geneva gear to be opposite the Geneva wheel when at tool position.

**CMD MENU** TURN COMMAND MENUS:

- 1)OFF
- 2)ON
- 3)TOGGLE ON WITH SPACE BAR

The operator may select the command menu display method.

**PALLET** DO YOU HAVE A PALLET CHANGER?

- 1)NO
- 2)YES

Select yes if a Fadal pallet changer is installed.

**GAIN** ENTER THE GAIN FACTOR FOR RIGID TAPPING  
THE FACTOR MUST BE BETWEEN 0 AND 255

This parameter effects the spindle response during rigid tapping. The higher the number the faster the spindle turns in relation to the feed rate. When the speed is too fast the thread may be too loose. See the Rigid Tapping Procedure in the “Spindle Drive and Motors” Section.

**RAMP** ENTER THE RAMP FACTOR FOR RIGID TAPPING  
THE FACTOR MUST BETWEEN 0 AND 255

This parameter sets the speed at which the spindle accelerates during rigid tapping.  
See the Rigid Tapping Procedure in the “Spindle Drive and Motors” Section.

**ASPECT** ENTER THE ASPECT RATIO OF Y TO X

THE RATIO MUST BE BETWEEN 25 AND 150

This parameter affects the look of the display. Program a circle and change the aspect to get a round circle on the display.

**TIMERS** SELECT THE AUTOMATIC TOOL TIMER MODE?

- 1)ALL TOOL TIMING OFF
- 2)DO NOT CHECK
- 3)END OF TOOL (AT M6)
- 4)AFTER EACH MOVE
- 5)AT END OF PROGRAM

Select the desired option and set a value in the DTT table for TIME. The USED value will be inserted by the control. See DTT command in Users Manual.



**OVERLOAD** ENTER THE MOTOR OVERLOAD FACTOR  
(2 IS STANDARD)  
THE FACTOR MUST BE BETWEEN 1 AND 8

This parameter determines the allowable following distance the actual axis position can be behind the computer commanded position. Each number is a turn of the ball screw.

---

**Machine Parameters:  
Page Three**

**SCREW** SELECT THE SCREW PITCH TYPE

- 1) INCH PITCH
- 2) 8/10 MILLIMETER PITCH

This parameter sets the type of ballscrews installed in the machine.

**DANGER!**

Serious damage to machine may occur if this parameter is set incorrectly.

**IPM** SELECT THE MAX RAPID FEED RATE

- 1) 400 IPM    4) 800 IPM
- 2) 500 IPM    5) 900 IPM
- 3) 700 IPM    6) 1000 IPM

This parameter sets the maximum rapid feed rate for the machine. Check machine specifications for proper setting.

**Caution!** Machine damage and excessive faults may occur if this parameter is set too high.

**XYZ RAMP** ENTER THE X, Y, & Z RAMP LENGTH  
FACTOR (160 IS STANDARD)  
THE FACTOR MUST BE BETWEEN 50 AND 200

This parameter sets the speed at which the axes accelerate and decelerate during travel. The typical standard settings are 160 for millimeter and 100 for inch ballscrews. For the 6536, 12 mm pitch screws, use 250. Lower numbers than the typical standard may be used for any machines. A lower number will result in faster accelerations/decelerations. Varying machine environments and parameters (ie rapid travel parameter) will affect the absolute minimum for a particular machine.

**Z TAP GAIN**     SELECT THE Z GAIN DURING RIPID  
TAPPING?

- 1)NORMAL
- 2)MEDIUM
- 3)HIGH

This parameter should be set to Normal for Millimeter and High for Inch ball screws. It determines the gain of the Amplifier.

**VECTOR**     DO YOU HAVE VECTOR DRIVE  
(10 RPM MIN)?

- 1)YES
- 2)NO

If the machine is equipped with a vector drive then this parameter will allow a 10 RPM minimum spindle speed. A closed loop Baldor or AMC drive is required for a yes response. Closed loop vector systems will have the encoder cable coming all the back the axis controller card used.

**AXIS DISPLAY**     DISPLAY THE AXIS FOLLOW ERROR OR  
LOAD?

- 1)LOAD PERCENTAGE
- 2)FOLLOWING ERROR

This option is used to select what the axis display will show on the position display while auto running a program. DC amplifiers can not display the load percentage.

**AUTO BRAKE**     AUTOMATICALLY APPLY THE A OR B  
BRAKE DURING IDLE TIME?

- 1)YES
- 2)NO

Select the option desired to activate or de-activate the air for the axes brake. The brake will apply after 75 seconds of non-activity.

**A-PALLET** WHICH ROTARY AXIS IS INSTALLED ON THIS PALLET?

- 1)NOT APPLICABLE
- 2)A-AXIS
- 3)B-AXIS
- 4)A-AXIS & B-AXIS

Select the appropriate option for the rotary axis being used.

**B-PALLET** WHICH ROTARY AXIS IS INSTALLED ON THIS PALLET?

- 5)NOT APPLICABLE
- 6)A-AXIS
- 7)B-AXIS
- 8)A-AXIS & B-AXIS

Select the appropriate option for the rotary axis being used.

**5TH AXIS HEAD** DO YOU HAVE THE 5TH AXIS PROGRAMMABLE HEAD ATTACHMENT?  
HEAD

- 1)NO
- 2)YES

Answer YES if a 4th or 5th axis rotary head attachment is installed in the spindle. This will turn on the vectoring jog when the axis selector is set to C.

**GO DETAIL** ENTER THE DETAIL DESIRED FOR GO MOVES BETWEEN 2 TO 240 TENTHS (241=OFF)

This command is a parameter that adjusts the tolerance of positioning in G0 Rapid moves. The smaller the number, the closer the machine is held to the commanded position before moving to the next position. Holding the rapid travel moves to a tight tolerance in the majority of cases is not needed. This parameter just allows flexibility for the rapid travel move. VMC's are shipped with this parameter set at 241, which is the OFF setting. Setting the value too low will slow the machine down considerably.

**AIR VALVE  
FEEDBACK** DO YOU HAVE AIR VALVE FEEDBACK?

- 1)NO
- 2)YES

Answer NO only for machines built previous to having feedback on the drawbar.

**AT SPEED** WAIT UNTIL SPINDLE IS AT-SPEED BEFORE  
NEXT BLOCK IS EXECUTED?

- 1)NO
- 2)YES

This will inhibit any axis motion until 80% of the commanded RPM is achieved.

**ENTER SLIDE HOLD RAMP FACTOR  
BETWEEN 1 TO 10 (10 IS STANDARD)?**

This parameter will change the amount of time permitted to bring the machine to a Slide Hold condition. The typical setting is 10, this is about 250 milliseconds. Lower values may be used, but the higher the feed rate of the machine the more deceleration time will be needed to avoid amplifier faults.

**IS THIS A MANUAL MACHINE WITH 1 MPG FOR EACH AXIS?**

This will enable the manually operated machines (i.e. TRM, Tool Room Mill). Setting this parameter incorrectly will cause the JOG mode to malfunction.

**SLIDE HOLD** ENTER SLIDE HOLD RAMP FACTOR  
BETWEEN 1 TO 10 (10 IS STANDARD)?

This parameter controls the ramp after pressing Slide Hold. Depending on the size of the machine and customer preference, this parameter can be made smaller to generate sharper stops after pressing slide hold. The default value is 10. If the number is too small the machine could generate Amplifier Fault #18. Choose a number that best fits desired results without causing faults.

**MANUAL** IS THIS A MANUAL MACHINE WITH 1 MPG FOR EACH AXIS?

This parameter enables the “Manual” feature of some machines. Manual machines are those that are outfitted with separate MPG handwheels on each axis, as on the Tool Room Mill machine. Set the parameter to YES if it has these MPG on each axis. If the machine does not have separate MPG handwheels on each axis the parameter must be set to NO.

---

**Typical TRM  
Parameters**

The following parameters in red are the typical settings for the Tool Room Mill machine:

PAGE 1 OF 3

*FORMAT: 1	BAUD RATE: 2400	SPINDLE AFTER M6: NO
AXES: X,Y,Z	TRAVEL: X30 Y14 Z14	PENDANT: MOUNTED
DEFAULT: G1		
DEFAULT: G91		
DEFAULT: G17	TOOL CHANGER CAP: 0	IMM. FIXED CYCLE: NO
RPM FACTOR: 5	SPINDLE TYPE: 4,000	ORIENTATION FACTR: 10

PAGE 2 OF 3

*DEFAULT: INCH	_M8=FLOOD M7=MIST	3 PHASE > 5% LOW: NO
PU FORMAT: FILE		
CRC MODE: M96	BINARY BUFFERS: 255	HI TORQUE/RIGID: NO
SPINDLE OFF: NO	TURRET FACTOR: 1	CMD MENU: SPACE
PALLET: NO	GAIN: 100	RAMP: 100
ASPECT: 65	TIMERS: OFF	OVERLOAD: 2

PAGE 3 OF 3

*SCREW: #1	IPM: 200	XYZ RAMP: 100
Z TAP GAIN: HI	VECTOR: NO	AXIS DISPLAY: LOAD
AUTO BRAKE: YES	A-PALLET: A-AXIS	B-PALLET: B-AXIS
5 AXIS HEAD: NO	GO DETAIL: 241	FEEDBACK: NO
AT-SPEED: NO	SLIDE HOLD: 10	MANUAL: NO

---

**15" (SHARP) LCD  
display**

Here are the settings for the 15" LCD Display unit used with the Fadal Control:

Clock: 127  
Phase: 0  
H Pos: 12  
V Pos: 34  
640x480V:60Hz    H:31.4 KHz

Black Level: 68  
Contrast: 29

400 Lines    640    720  
Expand: ON1    ON2  
Scaling: 3  
Bright: Auto    Low    Med    High    if Auto selected set to 31.

